Before first time using the IAQ6-1 Adaptor, install the USB Driver on your PC computer.

- From the CD run the file:

  CP210x_VCP_Win2K_XP_S2K3.exe

- Make sure the file is opened into the default path:

  C:\SiLabs\MCU\CP210x\Windows_2K_XP_S2K3

- From the folder named:

  C:\SiLabs\MCU\CP210x\Windows_2K_XP_S2K3

  Run the file: CP210xVCPInstaller (It might take about 60sec. to install(

- After the installation is complete, connect the USB device.

  The computer automatically will find and install the device.

- If program does not start automatically look for the driver in the following folder:

  C:\Program Files\Silabs\MCU\CP210x\

  and start the file manually.