



Detnov Cloud Card  
TED-151-CL



Ref. 55315015

### Installation<sup>1</sup>



1. Write down the serial number ( see image below)
2. Place the jumper in the conventional or analog position based on the panel to which the card is connected to.
3. Place the card in its location ( see images above).
4. Connect the card to the network by using the RJ-45 port.




<sup>1</sup> Compatible FW versions: from version 2.83 and above for addressable panels and for conventional panels acquired from 2016 and forward.

### Starting the APP<sup>2</sup>


1. Log in with user and password.<sup>3</sup>
2. Access the main menu by clicking the icon on the top left corner.



3. You can change the language from the settings menu.



4. To activate the installation, enter the serial number shown on the card.



<sup>2</sup>The DETNOV APP application can be downloaded from the Appstore (iOS) and Playstore (Android) for free.

<sup>3</sup>In case of not knowing your user details, please contact your account's administrator.

<sup>4</sup>For more information please check the complete user manual available within the app.